



## How to:

# WINDOW FILM ADHESIVE REMOVER

## WINDOW FILM REMOVAL INSTRUCTIONS

### FILM REMOVAL

1. Spray solution onto film. Cover with plastic (leaf or garbage bag) and seal with masking tape. After 30 minutes, uncover top edge and test with finger nail to see if film can be peeled from glass. If not, respray and reseal, testing every 30 minutes until film can be peeled from glass.
2. Slide razor blade under a top corner of film and carefully pry 1-2" loose. Tug downward on corner to pull film free. Repeat on remaining top corner. If film resists, spray solution onto sticking point and pry loose with blade.
3. Pull the remainder of film downward with both hands. Discard.

### ADHESIVE REMOVAL

4. Spray solution onto residual adhesive. Soak for 3-5 minutes. Repeat until adhesive becomes milky white.
5. Starting at the top of the glass, use a sharp razor blade to shave the adhesive downward. Keep glass wet so adhesive can be removed smoothly. Carefully wipe excess adhesive from blade with tissue. Continue until all adhesive is removed. Discard used blades.

### SPECIAL TIPS

- Apply masking tape to the bottom of auto windows to keep adhesive out of crevice.
- Solution works best when the interior glass temperature is 65-75°F.
- After removing old film, wait at least 24 hours before applying new film.
- Use caution when removing film from glass with defroster wires. Damage could occur. Once film is removed, respray the adhesive and rub briskly with paper towels or non-scratching nylon pads; do not use a razor blade.

Check Out Our  
Step-By-Step  
Installation  
Videos Here:

